


DYNA-KING®
 World's Finest Hand Crafted Fly-Tying Vises and Accessories

THE BARRACUDA & BARRACUDA JR.




PARTS LIST

Figure 1

- | | |
|--|--|
| 1. Bearing Housing | 16. Set Collar -available on clamp models only |
| 2. Body | 17. Extra Large Pedestal Base |
| 3. Cam Handle | 18. Base Lock Screw |
| 4. Centering Gauge-available separately for purchase | 19. Base Feet |
| 5. Tension Screw | 20. Name Plate |
| 6. Forcing Cone | 21. Bobbin Hanger Wire |
| 7. Slide Lock Screw | 22. Bobbin Hanger Mount |
| 8. Jaw | 23. Bobbin Rest |
| 9. Rotary Lock Screw | 24. Bobbin Hanger Screw |
| 10. Hub Handle | 25. Built In Material Clip |
| 11. Hub | 26. Serial Number |
| 12. Shaft Adaptor | 27. Hub Handle Ball |
| 13. Shaft | 28. Set Screw (3) |
| 14. Spindle | |
| 15. Cam Pin | |

The Barracuda Junior comes with all components listed with the exception of the following:
 1. Double Material Clip in place of the Single Material Clip Shown in diagram (#25)

Figure 2



PARTS LIST

Figure 2

- | | |
|----------------------|---|
| 1. Clamp Base | 7. Top View of Clamp with Outrigger installed |
| 2. Clamp Shoe | 8. Side View Of Outrigger |
| 3. Clamp Handle Knob | |
| 4. Clamp Screw | |
| 5. Clamp Lock Screw | |
| 6. Outrigger | |

Clamp Vises come with a 9" shaft. Pedestals come with a 7" shaft.