


the BARRACUDA JUNIOR TREKKER

Figure 1




PARTS LIST

Figure 1

- | | |
|--------------------|-------------------------|
| 1. Jaw | 13. Slide Lock Screw |
| 2. Forcing Cone | 14. Bobbin Hanger Mount |
| 3. Vise body | 15. Bobbin Hanger Wire |
| 4. Cam Handle | 16. Bobbin Rest |
| 5. Sleeve Adaptor | 17. Bobbin Hanger Screw |
| 6. Spindle | 18. Large Pedestal Base |
| 7. Bearing Housing | 19. Base Lock Screw |
| 8. Tension Screw | 20. Name Plate |
| 9. Hub | 21. Base Feet |
| 10. Hub Handle | 22. Set Screw |
| 11. Shaft | 23. Serial Number |
| 12. Cam Pin | |

Figure 2



PARTS LIST

Figure 2

- | | |
|----------------------|---|
| 1. Clamp Base | 7. Top View of Clamp with Outrigger installed |
| 2. Clamp Shoe | 8. Side View of Outrigger |
| 3. Clamp Handle Knob | |
| 4. Clamp Screw | |
| 5. Clamp Lock Screw | |
| 6. Outrigger | |

The **SHAFT** of the **TREKKER** is threaded at the top & screws into the **BEARING HOUSING (#7)**. To remove the **SHAFT (#11)** it must be clamped into a bench vise. Use a cloth to wrap around the **SHAFT** so it won't be marred. Just grasp the Top portion of the vise and unscrew. When replacing the **SHAFT** be sure to not cross thread the **SHAFT** or **BEARING HOUSING** & tighten until very snug to prevent your vise from coming loose from the **SHAFT** while tying.

The pedestal version does not come with a Set Collar. The clamp version comes with a Delrin Set Collar.